

# Tekloom Cleaning Guide



**Patterns: Gravity, Relativity, Static**

## **General Maintenance:**

While Tekloom® is inherently stain resistant, it is important to keep it clean at all times to maintain the original look and feel. Spot cleaning with a clean, soft towel with clean water will remove most of the everyday stains.

Cleaning Code: Bleach, W/S (1:9), Dry Care™

## **Disinfection:**

This product can be disinfected with a 1:9 bleach dilution of water/bleach. Apply the solution using a misting spray bottle and gently scrub the affected area with a sponge or soft bristle brush. Allow the mixture to linger for the time specified by the Center for Disease Control and Prevention.

*Avoid soaking the seamed area to prevent the bleach from penetrating through the protective layer.*

*Rinse all cleaning agents thoroughly with water and wipe with a soft cloth.*

*Residue left by cleaning agents will degrade and shorten the life and/or affect the product's appearance if not removed.*

## **Approved Healthcare Cleaners:**

This list represents some of the most common options available and is not intended to be comprehensive.

- |  |  |
|--|--|
| • 3M C Diff Solution Tablets                                     | • Hydrogen Peroxide                          |
| • 3M Neutral Quat Disinfectant Cleaner Concentrate 23H           | • Lysol Disinfectant Spray                   |
| • 3M Neutral Quat Disinfectant Cleaner Concentrate 23L           | • Oxivir 1                                   |
| • 3M HB Quat Disinfectant 25L                                    | • Oxivir 5 16                                |
| • Amphyl   | • Oxivir Plus                                |
| • CariCide   | • Oxivir Tb Wipes                            |
| • CaviWipes XL   | • Oxycide                                    |
| • Clorox Healthcare Hydrogen Peroxide Cleaner Disinfectant Wipes | • Perisept                                   |
| • Ecolab A456 II   | • Sani-Cloth AF3 Germicidal Disposable Wipes |
| • Ecolab Neutral Disinfectant Cleaner                            | • Steris (Coverage Spray HB Plus)            |
| • Formula 409  | • Stride Fragrance Free SC Neutral Cleaner   |
|  | • Virex 256                                  |
|  | • Virex Plus                                 |
|  | • Wexcide 128                                |

*\*Tekloom® protects the woven fabric with a patented, clear TPE layer. All approved cleaning chemicals should stay on the surface. Avoid soaking the seamed area to prevent the cleaning chemicals from entering the base fabric or the foam underneath.*